

Schedule of works

Upon arrival

Check for fault conditions on control panel

Control panel

Check internal control components

Check lamps

Check sounder

Check stepping relay (if applicable)

Check battery condition

Level controls

Check level controls

Check level controls sequence

Excluded

Incoming power supply

Edincare may be unable to inspect all aspects of the equipment due to, for example, inaccessibility of equipment, adverse weather conditions, or where the customer has not followed the installation guidelines. Edincare Terms and Conditions apply.

NOTES

Schedule of works

Batteries

Check terminal connections

Check battery output

Check battery age

Final

Check pump/s running in Auto mode.

Check system running in mains mode.

Check system running in battery mode.

Check control panel closed and switched On/System switched On