

## Schedule of works

### Upon arrival

Lay floor protection, where required

### Access cover

Check access cover

### Manhole/Chamber/Sump

Remove access cover

Inspect manhole/chamber/sump

Survey and record waste water type

Setup jetter

Connect jetter fill hose to water supply, where applicable

Jet clean the pipework and manhole/chamber/sump

### Final

Check access cover and replaced/secured

Remove floor protection

*Edincare may be unable to inspect all aspects of the equipment due to, for example, inaccessibility of equipment, adverse weather conditions, or where the customer has not followed the installation guidelines. Edincare Terms and Conditions apply.*

## NOTES