

Operation

Service provided (where applicable)	Details
Check pressures	Check pressure within the system pipework.
Clean strainers	Remove and clean strainers.
Check isolation valves	Test each valve operation and holding.
Check panel fans & filters	Check fans and filters (where fitted), and replace if necessary.
House keeping	Remove surface dust from valve.
Service label	Fill sticker with correct information (date, initial and comments).
Check coil resistances	Check the coil resistances are within tolerance.

Reports

Service provided (where applicable)	Details
Report information	<p>The following to be recorded for report writing.</p> <ul style="list-style-type: none"> • How found, what done and how left. Record general observations • System type • Unit serial number • Valve(s) make/model • Safety valves rating • Static height of system • Dropdowns completed • Panel Type • Off load voltage • On load voltage • Coil current • Coil resistance

All of the above must be carried out in accordance with the designated Safe Systems of Work i.e. Generic or Site Specific Risk Assessment and Method Statement.

Edincare may be unable to inspect all aspects of the equipment due to, for example, inaccessibility of equipment, adverse weather conditions, or where the customer has not followed the installation guidelines. Edincare Terms and Conditions apply.

NOTES